

Subassemblies in assembly order

Hardware included - core mechanism and removable hand rest

Use the numbered views from 01 to 19. Each view identifies the hardware and shows the assembled result.
Before the full print: test the fit coupon, one bearing socket, the actual nuts and one spring-return plunger.
The right-hand rest with a 4 mm spacer is illustrated. Other hand and height options are shown in step 18.

FRAME / RAILS

- 01 Join the side bases
- 02 Join the three tray sections
- 03 Raise the tray on six pedestals
- 04 Mount the fixed X rail posts
- 05 Dock the tray to the side bases
- 06 Prepare the moving X feet
- 07 Install the two low X rails

FIVE-KEY HEAD

- 08 Prepare the two Y carriages
- 09 Fit the four adjustable guides
- 10 Build the spring-return plungers
- 11 Assemble the inner joystick pivot
- 12 Fit the gimbal to the upper frame
- 13 Close the head stack
- 14 Fit the grip and center button

FINAL ASSEMBLY

- 15 Attach the head to the Y carriages
- 16 Install the head and the Y rods
- 17 Fit the three drag knobs
- 18 Attach the hand rest
- 19 Align contacts and check the fit

Load captive nuts before closing parts. Fit the cross gate before the grip and center button.


Fit the hand rest after the head attachments and drag knobs so the mounting screws remain accessible.

Printed prototype demonstrated. Revised grip fit, hand support and working-keyboard tests remain.

01 Join the side bases


Build both sides

MX GLIDE / V5



- 01 4 base sections**
C03 left/right, front/rear
- 02 4 splice bars**
R04_splice_bar
- 03 8 M3 x 10 screws**
No washers
- 04 8 M3 nuts**
Underside seam pockets

After this step




1. Load eight M3 nuts into the underside seam pockets before adding the splice bars.
2. Join each front/rear pair with two R04 bars and four M3 x 10 screws. Use no washers.
3. The left and right groups are drawn closer together here; keep them separate on the bench.

02 Join the three tray sections


Build one tray

MX GLIDE / V5



- 01 3 tray sections**
C01_raised_tray_1 / 2 / 3
- 02 4 splice bars**
R04_splice_bar
- 03 8 M3 x 10 screws**
No washers
- 04 8 M3 nuts**
Underside seam pockets

After this step




1. Load eight M3 nuts into the underside seam pockets. Align the sections in order 1, 2, 3.
2. Bridge both seams at the front and rear flanges with four R04 bars.
3. Use eight M3 x 10 screws without washers. Keep the keyboard seating surface level.

03 Raise the tray on six pedestals


Add six supports

MX GLIDE / V5



- 01 6 pedestals**
R02_tray_pedestal_20mm
- 02 6 M3 nuts**
Insert through pedestal side slots
- 03 6 M3 washers**
OD 7 x 1 mm
- 04 6 M3 x 12 screws**
Through the tray

After this step




1. Slide one M3 nut through the side slot of each pedestal before placing the tray.
2. Fit six M3 x 12 screws with 1 mm washers through the tray into the pedestals.
3. The tray underside is 20 mm above the desk; tighten evenly so the tray sits flat.

04 Mount the fixed X rail posts

One corner shown - repeat four times

MX GLIDE / V5



01 1 rail post per corner

R06_low_x_rail_post

02 2 M4 nuts per corner

Total for four posts: 8


03 2 M4 washers per corner

OD 9 x 1 mm; total: 8

04 2 M4 x 12 screws per corner

Hex head; total: 8

After this step




1. While the side bases are separate, load two M4 nuts into the underside pockets at each corner.
2. Fit one R06 post with two M4 x 12 hex-head screws and two 1 mm washers.
3. Point the bores left/right, with all four rod axes 20 mm above the desk. Keep the bases separate until step 5.

05 Dock the tray to the side bases


Connect all four corners - rail posts already fitted

MX GLIDE / V5



- 01 4 step brackets**
R05_tray_to_stage_step_bracket
- 02 8 M3 x 10 screws**
No washers
- 03 8 M3 nuts**
Four base + four tray pockets

After this step




1. Load four M3 nuts under the bases and four under the tray docking holes before bringing the assemblies together.
2. Use one R05 step bracket and two M3 x 10 screws at each corner, without washers.
3. Rotate the two right brackets 180 degrees around the vertical axis. Keep all feet on the desk.

06 Prepare the moving X feet


One foot shown - build two

MX GLIDE / V5



- 01 1 bridge foot**
C07_bridge_x_foot; print 2
- 02 2 LM10UU bearings per foot**
10 ID x 19 OD x 29 mm; total: 4
- 03 2 bearing caps per foot**
R08; total: 4
- 04 4 M3 x 10 screws per foot**
Total: 8; printed pilots
- 05 2 M3 nuts per foot**
Y-rod retention; total: 4
- 06 1 M4 nut per foot**
X drag; total: 2

After this step




1. Insert one LM10UU bearing from each end. Fit two R08 caps with four M3 x 10 screws per foot.
2. The cap screws form threads in printed pilot holes: use no nuts or washers at the caps.
3. Before installing rods, load two M3 retention nuts and one M4 drag nut in each foot.

07 Install the two low X rails


Join the fixed frame and moving feet

MX GLIDE / V5



- 01 2 smooth X rods**
Diameter 10 x 580 mm
- 02 2 prepared moving feet**
From step 6
- 03 4 M3 retention nuts**
Fixed rail-post side pockets
- 04 4 M3 x 10 screws**
Rod retention; heads may stand proud

Then pad the tray and seat keyboard




1. Slide a prepared X foot onto each 10 x 580 mm rod, then insert the rods lengthwise through the fixed posts.
2. Load four M3 post nuts and fit four M3 x 10 retention screws. Square the rails, then tighten only to rod contact.
3. Add 1 mm non-slip tray padding. Fold the keyboard tilt feet and seat the keyboard now, while the head is off.

08 Prepare the two Y carriages


Left carriage shown - build both

MX GLIDE / V5



- 01 1 Y carriage shown**
C09_y_carriage_with_head_legs; total: 2
- 02 2 LM8UU bearings per carriage**
8 ID x 15 OD x 24 mm; total: 4
- 03 2 C10 end caps per carriage**
Total: 4
- 04 4 M3 x 10 screws per carriage**
Total: 8; printed pilots
- 05 1 M4 drag nut**
Left boss for a right-hand rest

After this step




1. Insert two LM8UU bearings into each carriage and fit two C10 caps with four M3 x 10 screws.
2. Build the other side from the same printed part rotated 180 degrees; point both mounting arms inward.
3. For the right-hand rest shown later, load one M4 drag nut in the left carriage. Keep the Y rods out.

09 Fit the four adjustable guides


Start the lower head assembly

MX GLIDE / V5



- 01 **1 lower head frame**
07_head_stator
- 02 **4 adjustable guides**
08_plunger_guide
- 03 **4 M3 nuts**
Underside adjustment slots
- 04 **4 M3 washers**
OD 7 x 1 mm
- 05 **4 M3 x 10 screws**
Leave adjustable

After this step






1. Load four M3 nuts into the stator underside slots. Put each guide boss into its opening, with its ear outward.
2. Fit four M3 x 10 screws and four 1 mm washers. Leave the guides loose enough to adjust.
3. The illustrated stagger is a starting position; align the actual keys during calibration.

10 Build the spring-return plungers

One shown - build four

MX GLIDE / V5



01 1 direction plunger

09_direction_plunger; total: 4

02 1 direction return spring

Total: 4; stiffness chosen by trial

03 Fitted guide from step 9

08_plunger_guide

04 1 contact foot

10_contact_foot; four directional feet


05 1 M3 x 8 screw

From below; total directional screws: 4

06 1 soft contact pad

Diameter 8 x 0.5 mm; total: 4

After this step




1. Place a direction spring around the shaft and insert the plunger downward through its fitted guide.
2. Attach the contact foot from below with M3 x 8. Cover the recessed screw head with an 8 x 0.5 mm soft pad.
3. Check free return and 5 mm downward travel. Spring OD ≤ 8.2 , ID ≥ 5.5 , free length about 10 mm; no coil bind.

11 Assemble the inner joystick pivot


Two pivots through the Y faces

MX GLIDE / V5



- 01 **1 outer gimbal**
11_outer_gimbal
- 02 **1 cam and hollow stem**
12_joystick_cam_stem
- 03 **2 M3 nyloc nuts**
Inside the stem lugs
- 04 **2 M3 washers**
OD 7 x 1 mm; in the gaps
- 05 **2 M3 x 20 screws**
Inner pivots

After this step




1. Place the cam/stem inside the outer gimbal and align its two lugs with the Y-face holes.
2. Use two M3 x 20 screws, two 1 mm washers in the gaps and two M3 nyloc nuts inside the lugs.
3. Adjust for little play and free rotation. These are two of the eight M3 x 20 screws needed for the whole build.

12 Fit the gimbal to the upper frame


Two outer X pivots

MX GLIDE / V5



- 01 1 upper head frame**
06_x_carriage_upper
- 02 Inner mechanism from step 11**
Gimbal + cam/stem + two pivots
- 03 2 plain M3 nuts**
Inner X-face hex sockets
- 04 2 printed head spacers**
18_outer_pivot_head_spacer; 1.5 mm
- 05 2 thin M3 washers**
OD 7 x 0.5 mm
- 06 2 M3 x 20 screws**
Outer pivots; use this exact length

After this step




1. Load two plain M3 nuts in the gimbal inner X-face hex sockets before fitting the mechanism into the frame.
2. Each M3 x 20 pivot needs a printed 1.5 mm spacer and a 0.5 mm outer washer, making a 2 mm head stack.
3. Set free pivoting and check the screw tips finish flush with the gimbal inner face. Use removable threadlocker.

13 Close the head stack


Fit the gate before the grip; preload eight nuts

MX GLIDE / V5



- 01 Completed lower assembly**
From steps 9-10
- 02 Completed upper mechanism**
From steps 11-12; grip still off
- 03 1 cross gate / transport loop**
13_cross_gate_transport_loop
- 04 4 M3 post nuts**
Side pockets near stator post tops
- 05 4 M3 side-attachment nuts**
Upper frame underside ear pockets
- 06 4 M3 washers**
OD 7 x 1 mm
- 07 4 M3 x 30 screws**
Two will be replaced in step 18

After this step




1. Load four M3 nuts into the stator post tops and four more into the underside pockets of the upper-frame side ears.
2. Lower the upper mechanism onto the posts and add the cross gate, with its transport loop toward the user.
3. Join with four M3 x 30 screws and 1 mm washers. Check gimbal tilt and plunger travel. Fit the wider grip after the gate.

14 Fit the grip and center button


Fit after the cross gate - keep collar access clear

MX GLIDE / V5



- 01 **1 center pushrod/button**
15_center_pushrod_button
- 02 **1 center return spring**
OD <= 10; ID >= 6.8; free length 10-12 mm
- 03 **1 hollow grip**
14_hollow_grip
- 04 **Grip: M3 x 6 + M3 nut**
Nut enters underside; screw head sits in side recess
- 05 **1 return-stop collar**
17_center_return_stop_collar
- 06 **Collar: M3 x 6 + M3 nut**
Face clamp toward the transport loop
- 07 **1 center contact foot**
10_contact_foot; fifth foot
- 08 **1 M3 x 8 foot screw**
Install from below
- 09 **1 soft center contact pad**
Diameter 8 x 0.5 mm

After this step




1. Insert M3 nut through underside socket into inside pocket. Fit grip after gate; retain with M3 x 6 in the head recess. Add center spring.
2. Insert the center rod and fit its collar below the cam, with the clamp facing forward toward the transport loop. Attach the padded foot with M3 x 8.
3. Set cap underside 8 mm above the main grip shoulder (5 mm above its raised stop). Set collar top against cam underside; clamp with M3 x 6 and nut.

15 Attach the head to the Y carriages

Keep both Y rods out for access

MX GLIDE / V5



01 Complete five-key head

From step 14

02 2 prepared Y carriages

From step 8; arms point inward


03 4 M3 washers

OD 7 x 1 mm

04 4 M3 x 20 screws

Use the existing captive ear nuts

After this step




1. Slide the prepared carriages inward from the two sides, with their mounting arms over the upper-frame ears.
2. Fit four M3 x 20 screws and four 1 mm washers into the captive ear nuts loaded in step 13. Tighten evenly.
3. The attachment holes are 47 mm to either side and 20 mm front/rear of the stick. Leave the hand rest off for tool access.

16 Install the head and the Y rods


Square the bridge before tightening

MX GLIDE / V5



- 01 Head/carrriage unit**
From step 15
- 02 2 smooth Y rods**
Diameter 8 x 240 mm
- 03 4 M3 x 12 screws**
Use the preloaded foot nuts

After this step




1. Support the head/carrriage unit between the X feet. Insert each 8 x 240 mm rod through a front post, carrriage and rear post.
2. Keep 124 mm between rod axes, at 70 mm above the desk. Center the rods; ends project about 2 mm beyond the posts.
3. Use four M3 x 12 retention screws in the nuts loaded in step 6. At contact the heads stand about 2 mm above the posts.

17 Fit the three drag knobs


Two X knobs and one Y knob

MX GLIDE / V5



- 01 **1 knob shown; fit 3**
16_m4_drag_knob
- 02 **1 M4 x 25 nylon screw shown**
Fit 3; hex head 7 mm across flats
- 03 **Preloaded M4 nut**
One per knob

All three installed




1. Seat each M4 x 25 nylon hex head inside a printed knob, then thread the screw into its preloaded M4 nut.
2. Fit two knobs on the X feet and one on the left Y carriage for the right-hand-rest configuration.
3. Start with the tips barely touching the rods. Set enough drag to hold position while operating the joystick.

18 Attach the hand rest


Right side shown - 4 mm spacer

MX GLIDE / V5



- 01 1 removable soft pad**
About 3 mm foam or silicone
- 02 2 M4 x 16 button-head screws**
For the 4 mm spacer
- 03 2 M4 washers**
OD 9 x 1 mm
- 04 1 universal cradle**
H03_universal_edge_cradle
- 05 Optional 4 mm spacer**
H04; use one spacer or none
- 06 2 M3 x 35 + 0.8 mm washers**
Replace two stack screws and washers
- 07 1 right bracket**
H01; H02 is the left alternative
- 08 2 M4 nuts**
Bracket underside pockets

After this step




1. Load two M4 nuts into the bracket first. Replace only the two right-side M3 x 30 stack screws and washers with M3 x 35 and 0.8 mm washers.
2. Fit bracket, optional 4 mm spacer and cradle. Use two M4 x 16 button-head screws with 1 mm washers. Adjust the fore/aft slots.
3. Add the removable pad. Left hand: use H02 and keep Y drag on the right. No spacer: M4 x 10; 8 mm spacer: M4 x 20.

19 Align contacts and check the fit

Final calibration - assembled view

MX GLIDE / V5



01 Five adjustable contact positions

Four tilt directions + independent center


02 Hand rest and movable head

Set cradle position and comfortable drag

03 Padded keyboard tray

Keyboard seated in step 7 on 1 mm padding

Keyboard / padding / tray



1. Center one contact over a key, then slide the four guides over actual neighboring keys and tighten their screws.
2. Check that all padded feet clear the keys at rest and during X/Y movement. Trial the hand support and finger reach.
3. Test direction and center action in a text editor. Check return, unwanted keystrokes and comfortable effort.

Installed hardware - right-hand rest, 4 mm spacer

Screw lengths are measured under the head. These are installed quantities; keep spares separately.

HARDWARE	QTY	HARDWARE	QTY
Center return spring	1	M3 x 30 socket-head screw	2
Direction return spring	4	M3 x 35 button-head screw	2
M3 nyloc nut	2	M3 x 6 socket-head screw	2
M3 plain nut	54	M3 x 8 socket-head screw	5
M3 washer, OD 7 x 0.5 mm	2	M4 plain nut	13
M3 washer, OD 7 x 0.8 mm	2	M4 washer, OD 9 x 1 mm	10
M3 washer, OD 7 x 1 mm	18	M4 x 12 hex-head screw	8
M3 x 10 socket-head screw	48	M4 x 16 button-head screw	2
M3 x 12 socket-head screw	10	M4 x 25 nylon hex-head screw	3
M3 x 20 socket-head screw	8		

Rods and bearings

2 x diameter 10 x 580 mm rods; 2 x diameter 8 x 240 mm rods; 4 LM10UU; 4 LM8UU.

Soft parts: five diameter 8 x 0.5 mm key pads, 1 mm tray padding, one removable hand cushion.

Hand-rest heights: no spacer / M4 x 10; 4 mm spacer / M4 x 16; 8 mm spacer / M4 x 20.

Use one spacer or none. The two M3 x 35 screws replace two M3 x 30 screws.

M3 x 20: eight required across the build - four pivots and four head attachments.