



Adventure Force Jurassic Pro Trigger Slop Remover



Transmogrification Labs

[VIEW IN BROWSER](#)

updated 9. 8. 2022 | published 9. 8. 2022

Summary

A simple alternative to a dedicated quick trigger. Removes slop from the trigger on the Adventure Force Jurassic Pro.

[Toys & Games](#) > [Outdoor Toys](#)

Tags: [adventure](#) [blaster](#) [foam](#) [force](#) [hair](#) [hairpin](#)
[jurassic](#) [pro](#) [quick](#) [remover](#) [trigger](#) [slop](#)

Currently at v1.0

Print at 0.28mm layer height (base is 0.84mm = 3 * 0.28mm)

Peg goes into slot on trigger behind the screw post (limiting the return travel and therefore the distance required to release the catch from starting position). Then put the screw back through the hole of the piece and into the screw post. Make sure to not tighten the screw too much or you will restrict movement of the trigger and may cause binding.

Model files



af-jp-trigger-slop-remover-v10.stl

📄 v1.0

License ©



This work is licensed under a
[Creative Commons \(4.0 International License\)](#)

Attribution-ShareAlike

-
- ✗ | Sharing without ATTRIBUTION
 - ✓ | Remix Culture allowed
 - ✓ | Commercial Use
 - ✓ | Free Cultural Works
 - ✓ | Meets Open Definition