



Klickfix Adapter for e-Scooter Ninebot G30D II

 **dfrommi**

[VIEW IN BROWSER](#)

updated 1. 8. 2023 | published 1. 8. 2023

Summary

Adapter to use Klickfix-holder with a Ninebot G30D II e-scooter.

[Sports & Outdoor](#) > [Outdoor Sports](#)

Tags: [klickfix](#) [ninebot](#) [escooter](#)

This adapter lets you mount the Klickfix holder to a Ninebot G30D II scooter. It might also fit to other variants of the G30. Please leave a comment if you've tried it.

Parts needed

- 4x M5x50 screws
- 4x M5 self-locking nuts

Assembly

Drill with a 5mm drill into the 4 existing screw-holes through the backside of the adapter.

An easy way to do it is to remove one screw, then drill, put the screw back in. Remove the next screw, drill, put back in and so on.



Press the “Adapter” print into the arc-profile of the Klickfix holder, as visible on the bottom of the picture above.

Put the tape that comes with the holder onto the two indented areas of holder- and adapter-print.

Use the M5 screws and nuts to put everything together.

References

The idea to drill through the adapter came from this model for Soflow cooter: <https://www.thingiverse.com/thing:5192238>

And the odd shape of the Ninebot-profile was taken from the Fusion-file of this AirTag-hook model: <https://www.printables.com/model/383237-e-scooter-bag-hook-with-airtag-compartment-fits-se>

This remix is based on



E-Scooter Bag Hook with AirTag Compartment - Fits Segway Ninebot


by Stefan



Klickfix Holder for Soflow Scooter

by KarstenWL

Model files



klickfix-g30d-holder.stl



klickfix-g30d-adapter.stl



klickfix-adapter-ninebot-g30d.f3d

License ©



This work is licensed under a
[Creative Commons \(4.0 International License\)](#)

Attribution—Noncommercial—Share Alike

-
- ✗ | Sharing without ATTRIBUTION
 - ✓ | Remix Culture allowed
 - ✗ | Commercial Use
 - ✗ | Free Cultural Works
 - ✗ | Meets Open Definition

