



Creality K1 chain delete



hirt.3dprint

[VIEW IN BROWSER](#)

updated 26. 11. 2023 | published 26. 11. 2023

Summary

the chain was bothering me on one of my K1

[3D Printers](#) > [Creality Parts & Upgrades](#)

Tags: [upgrade](#) [creality](#) [clips](#) [crealityk1](#)

If you have trouble with the chain or run the K1 without the lid at all this would be an option for you.

I run one of my K1 without a lid and the chain was bothering me. I have seen this design on some printers and thought to make my own quick design.

Please print in PETG, ABS or ASA and 0.2 layerheight

You need to remove the Faceplate and the cable holder. Disconnect the cable from the board plus the bowdentube from the extruder. Remove the chain from the cable (one main screw on toolhead and two on the housing). Install some of the clips (I used 4) on the tube and on the cable. Move the head in x and y to check for little adjustments of the clips.

Model files



k1-tube-and-cable-clip-v4.stl

License



This work is licensed under a
[Creative Commons \(4.0 International License\)](#)

Attribution—Noncommercial—Share Alike

-
- ✗ | Sharing without ATTRIBUTION
 - ✓ | Remix Culture allowed
 - ✗ | Commercial Use
 - ✗ | Free Cultural Works
 - ✗ | Meets Open Definition