



Prusa MK3 bed handle



GoToTheWall

[VIEW IN BROWSER](#)

updated 18. 1. 2023 | published 18. 1. 2023

Summary

Simple small profile bed handle for the Prusa MK3. Easy print and installation.



0.44 hrs



1 pcs



0.20 mm



0.40 mm



PLA



3 g



Prusa
MK3/S/S+

[3D Printers](#) > [3D Printers - Upgrades](#)

Tags: [bed](#) [handle](#) [mk3](#) [mk3s](#) [mk3splus](#)
[originalprusai3mk3](#) [printerupgrade](#) [printerupgrades](#)
[prusai3mk3](#) [prusai3mk3s](#) [prusamk3s](#) [prusaupgrade](#)
[upgrade](#) [upgrades](#) [bedhandle](#)

Simple small profile bed handle for the Prusa MK3. Great for moving the bed without touching the build surface or getting oils from the skin on the print bed. Especially helpful for holding the carriage in place while setting the magnetic flex plate in place. May not be compatible with older style y-carriages. Compatible carriage shown in images.

Installation:

- Remove the hex screw and spacer from the lower right corner of the y-carriage. Place the spacer into the hole in the stem of the handle. Use a finger to hold the spacer in place and slide the handle onto the carriage so that the spacer ends in its original position. Reinstall screw.
 - **Disassembly of the bed outside of the previous instructions should not be necessary.**
 - **As with any modifications to the printer, adjustment to the printer's z-offset may need to be done.**

Model files



prusa-mk3-bed-handle.stl

Print files



prusa-mk3-bed-handle_02mm_pla_mk3s_26m.gcode

🌀 PLA 🌀 0.40 mm 📏 0.20 mm ⌚ 0.44 hrs ⚖️ 3 g 📄 Prusa MK3/S/S+

📏 Uses 1.28 meters of filament

License ©

This work is licensed under a

[Creative Commons \(4.0 International License\)](#)



Attribution-ShareAlike

-
- ✗ | Sharing without ATTRIBUTION
 - ✓ | Remix Culture allowed
 - ✓ | Commercial Use

- ✓ | Free Cultural Works
- ✓ | Meets Open Definition