



Enhanced glasses temple tips (bent more for better hook behind ears)

[VIEW IN BROWSER](#)

updated 17. 5. 2022 | published 17. 5. 2022

Summary

Temples just like in original, but more angled, so they better hold behind ears.



0.56 hrs



6 pcs



0.20 mm



0.40 mm



PET



6 g



Prusa
MK3/S/S+

[Fashion](#) > [Other Fashion Accessories](#)

Tags: [glasses](#) [temples](#)

Info:

- glasses temples **bent more behind ear** than <https://www.printables.com/model/205857-fun-nerd-glasses-with-interchangeable-lenses-choose>
 - so glasses are more safely positioned
- **for usage with:**
 - <https://www.printables.com/model/205857-fun-nerd-glasses-with-interchangeable-lenses-choose>

- <https://www.printables.com/model/206056-party-fun-glasses-smart-ass-with-interchangable-le>

Print instructions:

- recommending **PETG** for flexibility (you know how many glasses you broke right?)
- increased infill - like 50%
- 3 perimeters
- test the length first to choose the right that fits your head
- use mirror in slicer to print the other one to the pair (or use 3mf or gcode)

Assembly (to the glasses):

- use short 1.75 filament piece and insert it into hinge
 - if filament is too loose, you can increase both ends sizes for example with putting something hot on to it, so it melts partially and creates larger heads
 - or glue one end to the hinge

This remix is based on



☺ **Party fun "nerd" glasses with interchangeable lenses (choose your own pattern)**

by

Model files



temples-enhanced-s.3mf



temple-enhanced-s.stl



temples-enhanced-m.3mf



temple-enhanced-m.stl



temples-enhanced-m-l.3mf



temple-enhanced-m-l.stl



temples-enhanced-l.3mf



temple-enhanced-l.stl



temples-enhanced-xl.3mf



temple-enhanced-xl.stl



temples-enhanced-xxl.3mf



temple-enhanced-xxl.stl

Print files



temples-enhanced-s_02mm_petg_mk3s_30m.gcode

⊗ PET ⊕ 0.40 mm ≡ 0.20 mm ⌚ 0.50 hrs ⚖ 5 g 🖨 Prusa MK3/S/S+



temples-enhanced-m_02mm_petg_mk3s_31m.gcode

⊗ PET ⊕ 0.40 mm ≡ 0.20 mm ⌚ 0.52 hrs ⚖ 5 g 🖨 Prusa MK3/S/S+



temples-enhanced-m-l_02mm_petg_mk3s_33m.gcode

⊗ PET ⊕ 0.40 mm ≡ 0.20 mm ⌚ 0.54 hrs ⚖ 6 g 🖨 Prusa MK3/S/S+



temples-enhanced-l_02mm_petg_mk3s_34m.gcode

⊗ PET ⊕ 0.40 mm ≡ 0.20 mm ⌚ 0.56 hrs ⚖ 6 g 🖨 Prusa MK3/S/S+



temples-enhanced-xl_02mm_petg_mk3s_35m.gcode

⊗ PET ⊕ 0.40 mm ≡ 0.20 mm ⌚ 0.58 hrs ⚖ 6 g 🖨 Prusa MK3/S/S+



temples-enhanced-xxl_02mm_petg_mk3s_36m.gcode

⊗ PET ⊕ 0.40 mm ≡ 0.20 mm ⌚ 0.60 hrs ⚖ 6 g 🖨 Prusa MK3/S/S+

License ©

This work is licensed under a
[Creative Commons \(4.0 International License\)](#)



Attribution-NonCommercial

- ✗ | Sharing without ATTRIBUTION
- ✓ | Remix Culture allowed

- ✖ | Commercial Use
- ✖ | Free Cultural Works
- ✖ | Meets Open Definition