



Original Enclosure Top Front Opening PTFE Coupler Mount



Uko

[VIEW IN BROWSER](#)

updated 2. 8. 2023 | published 2. 8. 2023

Summary

Keep filament outside, and connect the other end of a PTFE tube with a coupler to the top front opening of the enclosure



0.22 hrs



1 pcs



0.20 mm



0.40 mm



PET



2 g



Prusa MK4

[3D Printers](#) > [3D Printers - Upgrades](#)

Tags: [ptfetubemount](#)

[ptfecoupler](#)

[ptfetube](#)

[ptfe](#)

[prusaenclosure](#)

[enclosureparts](#)

[originalprusaenclosure](#)

[bowdentube](#)

[bowdenmount](#)

[enclosuremodification](#)

[enclosure](#)


[bowdencoupler](#)

Designed for the same QSM-M5-4 coupling that Prusa uses for the print head side.

ATTENTION: I found out that the springiness of the PTFE tube affects the first layer calibration of MK4 and ended up not using this approach to install a PTFE tube. But I suppose it can work absolutely well on MK3, and

maybe someone will figure out a good length of the tube, or a similar installation method that circumvents the issue. Of maybe the future software updates will ignore the error introduced by the tube.

This remix is based on



Enclosure Printable Parts

by Prusa Research

Model files



Slicer Project

1 file



top-hole-cover-w-bowden-coupler-print-setup.3mf

☐ With more perimeters for the hole where the coupler is threaded








top-hole-cover-w-bowden-coupler-v1.3mf

Print files



top-hole-cover-w-bowden-coupler-print-setup_04n_02m... .gcode

 PET  0.40 mm  0.20 mm  0.22 hrs  2 g  Prusa MK4

License

This work is licensed under a
Creative Commons (4.0 International License)



Attribution-ShareAlike

-
- ✗ | Sharing without ATTRIBUTION
 - ✓ | Remix Culture allowed
 - ✓ | Commercial Use
 - ✓ | Free Cultural Works
 - ✓ | Meets Open Definition