



## 3030 Chamber thermistor holder



Ferfi

[VIEW IN BROWSER](#)

updated 26. 11. 2023 | published 26. 11. 2023

### Summary

Holder for chamber thermistor to be placed on a 3030 extrusion.

[3D Printers](#) > [Accessories](#)

Tags: [holder](#) [3030extrusion](#) [chamber](#) [thermistor](#)

For any thermistor with 3 mm diameter cartridge.

Assembly:

1. Print it
2. Cut out the thin section acting as a support (circled in one of the images)
3. Get thermistor wire through newly created crevice
4. Pull the wire further so that thermistor cartridge is pulled towards hole
5. Lightly press the cartridge into the hole
6. Thermistor should get about 5 millimeters in and then stay put.

Most likely suspects that fit:

- a) ATC Semitec 104GT-2
- b) ATC Semitec 104NT-4-R025H42G

# Model files

chamber-thermistor-holder-atc-semitec-104nt-4-r025h... .stl



chamber-thermistor-holder-atc-semitec-104nt-4-r025h... .step

## License ©

This work is licensed under a  
[Creative Commons \(4.0 International License\)](#)



**Attribution-NonCommercial**

- ✗ | Sharing without ATTRIBUTION
- ✓ | Remix Culture allowed
- ✗ | Commercial Use
- ✗ | Free Cultural Works
- ✗ | Meets Open Definition